

WEST VIRGINIA CODE: §22-6-21

§22-6-21. Same -- Installation of fresh water casings.

When a permit has been issued for the drilling of an oil or gas well or both, each well operator shall run and permanently cement a string of casing in the hole through the fresh water bearing strata in such a manner and to the extent provided for in rules promulgated by the director in accordance with the provisions of this chapter.

No oil or gas well shall be drilled nearer than two hundred feet from an existing water well or dwelling without first obtaining the written consent of the owner of such water well or dwelling.

WV Legislature